Installation & assembly

1. Open the Plejd app and select **Add device**.

2. Press the rotary button on WRT-01 to activate it (active for 60 seconds). Select the device in the app and follow the installation steps.

3. Pull out the rotary button. Unscrew and remove the center plate. Mount the WRT-01 with tape or screw.

   For tape: check the range first by testing functionality from its intended location before taping the WRT-01 in place.

4. Mount the cover frame. Fasten the center plate and press the rotary button into place.